


HUAWEI E5577 のAPN設定方法

STEP
1

PCとE5577をWi-Fi接続後、Webブラウザのアドレス欄に「192.168.8.1」を入力して設定画面にアクセスして下さい。

STEP
2



ログイン

デバイスを保護するために、初期設定を完了してください。
初期設定では、デバイスのSSIDの変更、デバイスの自動更新、デフォルトのパスワードの変更が可能です。

ユーザー名:

パスワード:
 [パスワードを忘れた](#)

ユーザー名に「admin」を入力、パスワードに「admin」を入力し、「ログイン」をクリック

STEP
3



HUAWEI

日本語 ヘルプ admin ログアウト

設定

クイック設定

WLAN設定の構成

ステップ: 1/3

SSID (サービス設定ID)に名前を付ける: WLANの名前として最大32文字までの文字列を入力してください。

SSID:

パスワードの変更

個人情報保護方針 | Copyright © 2006-2017 Huawei Technologies Co., Ltd. | オープンソース通知 |

任意のSSIDを設定し次へをクリック

STEP
4

The screenshot shows the Huawei web management interface. At the top left is the Huawei logo and 'HUAWEI'. At the top right are links for '日本語', 'ヘルプ', 'admin', and 'ログアウト', along with signal strength, Wi-Fi, and battery icons. A dark navigation bar contains '設定'. Below it, a sidebar has 'クイック設定'. The main content area is titled '更新設定' (Update Settings) and 'ステップ: 2/3'. The text explains that the device will be updated automatically for efficiency and that automatic updates can be disabled later. Two radio buttons are present: '自動ダウンロード (再起動後に自動更新)' (selected) and '手動で更新する'. At the bottom right are '戻る' and '次へ' buttons. The footer contains '個人情報保護方針', 'Copyright © 2006-2017 Huawei Technologies Co., Ltd.', and 'オープンソース通知'.


任意の選択肢を選び、次へ

STEP
5

The screenshot shows the Huawei web management interface. At the top left is the Huawei logo and 'HUAWEI'. At the top right are links for '日本語', 'ヘルプ', 'admin', and 'ログアウト', along with signal strength, Wi-Fi, and battery icons. A dark navigation bar contains '設定'. Below it, a sidebar has 'クイック設定'. The main content area is titled 'パスワードの変更' (Change Password) and 'ステップ: 3/3'. The text explains that changing the password for web login prevents unauthorized users from changing settings and that passwords must be alphanumeric. It refers to a help link for password strength. There are four input fields: '現在のパスワード:', '新しいパスワード:', 'パスワードの強度:' (with '低', '中', '高' buttons), and 'パスワードの確認:'. At the bottom right are '戻る' and '終了' buttons. The footer contains '個人情報保護方針', 'Copyright © 2006-2017 Huawei Technologies Co., Ltd.', and 'オープンソース通知'.

任意の選択肢を選び、次へ

STEP
6



ホーム画面上部のタブより設定を選択

STEP
7



※設定タブの画面

STEP
8



左のメニューよりダイヤルアップ内のプロフィール管理を選択

STEP
9



プロフィール管理画面にて、新規のプロファイルをクリック

STEP
10



プロフィール、APN、ユーザー名、パスワードを入力後、保存をクリック

The screenshot shows the Huawei mobile settings application. At the top left is the Huawei logo and the word "HUAWEI". In the top right corner, there are links for "日本語", "ヘルプ", "admin", and "ログアウト", along with signal strength, Wi-Fi, and battery icons. Below the header is a navigation bar with "ホーム", "統計", "SMS", "更新", "設定", and "その他". The "設定" (Settings) menu is selected, and a sidebar on the left lists various settings categories: "クイック設定", "ダイヤルアップ", "モバイル接続", "→プロファイル管理" (highlighted), "モバイルネットワーク設定", "Wi-Fiエクステンダ", "WLAN", "DHCP", "セキュリティ", and "システム". The main content area is titled "プロファイル管理" (Profile Management). It contains a paragraph explaining APN (Access Point Name) and its role in connecting to the internet. Below the text are three input fields: "プロファイル名:" with a dropdown menu showing "クイック! mobile(デフォルト)", "ユーザー名:" with an empty text box, and "パスワード:" with a masked text box. The "APN:" field contains "vmobile.jp". At the bottom right of the main area are three buttons: "新規プロファイル", "削除", and "適用". The footer contains "個人情報保護方針", "Copyright © 2006-2017 Huawei Technologies Co., Ltd.", and "オープンソース通知".

日本語 ヘルプ admin ログアウト

ホーム 統計 SMS 更新 設定 その他

クイック設定

ダイヤルアップ

モバイル接続

→プロファイル管理

モバイルネットワーク設定

Wi-Fiエクステンダ

WLAN

DHCP

セキュリティ

システム

プロファイル管理

アクセスポイント名（APN）は端末が通信事業者のセルラーネットワークとパブリックインターネット間のゲートウェイとの接続を確立する際に読み込む設定の名前です。ほとんどの場合、ご利用の端末にはすでにAPNの設定がシステムファイル内に含まれており、接続時にAPN情報が自動的に入力されます。該当するAPNで自動的にインターネットに接続できない場合、手動でAPNを変更することもできます。

プロファイル名:

ユーザー名:

パスワード:

APN:

新規プロファイル 削除 適用

個人情報保護方針 | Copyright © 2006-2017 Huawei Technologies Co., Ltd. | オープンソース通知

プロファイル管理画面に現在設定されているプロファイルが表示されている